

HOW TO Interactive whiteboard




Website DigiLLabs


Switch on the board on the left using the power switch. The Smartboard can now be used in three different ways:




INTERACTIVE BOARD



- You can use the „Apps“ button to open various applications, such as a browser or YouTube.




- You can use this icon in the left-hand sidebar to add widgets, such as a stopwatch or a dice.



- Under „Files“, you can open files stored on the board or files from your USB stick. You can also create a new whiteboard file here.


In the whiteboard application, use the pens to write and the erasers or the back of your hand to erase what you have written.

EMBEDDED COMPUTER



- Select the „Computer“ input via the „Input“ menu and log in using your JMU credentials. Use the Smartboard as a touchscreen and, for applications that support pen input, use the board's pens as well.

EXTERNAL DEVICE




- Follow the same procedure as for the built-in computer, then select the desired input. HDMI ports are located on the left-hand side of the board and on the right-hand side behind the board.



- You can also use screen sharing with Windows, Android, macOS or iOS via the SMART Screen Share app.

BEFORE YOU GO



- Press the „Clean“ button to log out of any applications in the browser and save and delete the whiteboard in the library. Then press the power button to enter standby mode. Also, make sure the pens are properly secured in the magnetic strip and that the green ring is lit. This is the only way the pens will charge.